

Wireless microphone

USER'S MANUAL





MK-720 MK-770

www.sven.fi



Congratulations on your purchase of the SVEN Wireless Microphone!

COPYRIGHT

© 2018. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

BUYER RECOMMENDATIONS

- Shipping and transportation equipment is permitted only in the original container.
- · Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

APPLICATION

MK-720 / MK-770 microphone is designed for singing at home, online communication, recording words and phrases in distance learning of foreign languages and validation of their pronunciation. The microphone can be connected by a cable or wirelessly, by using receiver (included).

PACKAGE CONTENTS

- Microphone 1 pc
- Antenna 1 pc
- Receiver 1 nc
- AA type batteries 2 pcs
- XLR 6.3 mm jacksignal cable 1 pc
- User's Manual 1 pc
- Warranty card 1 pc

SAFETY PRECAUTIONS

- Do not install in locations where liquid, moisture, dust and high temperatures.
- Do not open or repair by yourself. In case of malfunction, contact the device for professional advice at your nearest service center.

SPECIAL FEATURES

- . Dynamic microphone in the plastic (MK-720) / metal (MK-770) case
- Wired / wireless transmission of audio signals

CONNECTING THE MICROPHONE

- Install the AA battery in the signal receiver. Observe the polarity as indicated on the receiver case.
- 2. Remove the battery cover. Install the AA battery into the microphone. Observe the polarity as indicated on the microphone case.
 - Observe the polarity as indicated on the microphone
- Connect the signal receiver to the sound source.
 Connect the antenna to the microphone.
- 5. Turn on the microphone and the receiver: Set switch to ON.
- To connect the microphone can use a cable that connects directly to the microphone. In this case, the battery is not required, and unmute the microphone by setting the switch in MIC position.



OPERATION OF MICROPHONE

 If the quality of microphone sound deteriorated, replace the microphone and receiver batteries. Also try to change the position of the receiver antenna to achieve optimum performance.

Attention. When you first turn on the signal quality is poor, it is necessary to conduct an accurate receiver tuning by adjusting the tuning element
(i) (Fig. 1) using a small screwdriver.

- 2. Remove the battery when you are not planning to use the microphone for a long time.
- 3. If you turn off the microphone may cause unwanted noise.
- 4. In case of insufficient signal quality or increase the noise level, it is necessary to adjust the receiver using a thin dielectric screwdriver. To do this, use a special hole (i) on the top of the device.

Attention!

- Protect the unit from direct sunlight and rain. Keep it away from electromagnetic waves.
- . Do not hold the microphone to the speaker, and to each other.



Fig. 1.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Microphone type	wired / wireless
Frequency, MHz	87.5-92.0
Transmitter power, mW	8
Membrane, mm	25
Microphone frequency range, Hz	80-13 000
Impedance, Ohm	600
Sensitivity dB	72
Microphone power	AA type battery – 1 pc
Receiver power	AA type battery – 1 pc
Range, m	up to 15
Interface	radio / 6.3 mm plug
Cable length, m	3
Microphone dimensions, mm	Ø 47 × 181
Receiver dimensions, mm	110 × 45 × 18
Microphone weight, g	100 (MK-720), 200 (MK-770)
Receiver weight, g	32

Notes. Technical specifications given in this table are supplemental information and cannot give occasion to claims. Technical specifications and package contents are subject to change without notice due to the improvement of SVEN production.

Technical support is on www.sven.fi.

Wireless Microphone

SVEN®



Model: MK-720/MK-770

Импортер в Россиис ООО «РЕГАРД», 105082, г. Москва, ул. Фундрирка Энгельса, д. 75, стр. 5. Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фундриеа Энгельса, д. 75, стр. 5. Условия гарантийного обслуживания смотрите в гарантийным талоне или на свёте www.sven.fl. Гарантийным срок: 12 мес.

Срок службы: 2 года.

Производитель: «CBEH ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.



MK-720 MK-770