

USER'S MANUAL



PS-68

www.sven.fi



Congratulations on your purchase of the SVEN speaker system!

COPYRIGHT

© 2017, SVEN PTE, LTD, Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

UNPACKING

- · Shipping and transportation equipment is permitted only in the original container.
- · Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

APPLICATION

SVEN PS-68 portable multimedia speaker system with Bluetooth and FM-radio is designed for operation with PC, notebooks and other mobile devices by means of data transfer via Bluetooth protocol. They can be also used in internet telephony, during video conferences, in multimedia applications, in interactive games. FM-tuner and the player with micro SD-cards are included.

PACKAGE CONTENTS

- Speaker system 1 pc
- Power cable/audio microUSB 3.5mm mini-jack/USB 1 pc
- Carabine 1 pc
- User's Manual 1 pc
- Warranty card 1 pc

SPECIAL FEATURES

- · Bluetooth wireless signal transmission
- . Built-in player for audio files from micro SD card
- Built-in FM tuner
- Wired connection
- · Soft-touch coating

Speaker system description

- 1 Headphones iack
- ② DC-LINE: micro USB jack for connecting speakers to the charger, the USB port of laptop / PC or to connect the audio signal (phone, MP3 player, etc.)
- ③ TF: micro SD card slot
- 4 M: Switching modes button: Bluetooth/Radio / Player/ AUX (short pressing)
- Volume level up button (long pressing);

Next track (in Player and Bluetooth mode):

Next station (in Radio mode)

(6) Play/Pause button (in Player and Bluetooth mode):

Start/Stop auto scan (long pressing in Radio mode);

Mute (short pressing in Radio mode);


Answer an incoming call. Press again to reset the incoming call

⑦ Volume level down button (long pressing);

Previous track (in Player and Bluetooth mode);

Previous station (in Radio mode)

- ® ON/OFF: POWER button
- Mode indicator






Fig. 1. Speaker system description



CONNECTION AND OPERATION

Attention! The built-in battery must be charged completely prior to the application.

Speaker system battery charging

- Connect speaker system to a USB port of PC or USB charger using micro USB to USB cable (included). During battery charging the indicator is red. Indicator will light green when the battery is charged.
- The battery is used in the speaker system as an integral part of the device, therefore do not try to extract or replace it, because this can result in the warranty cancellation or the device damage.

OPERATION MODES

Bluetooth mode

- Wireless data transfer via the Bluetooth protocol enables to connect speaker system to compatible devises. Maximum radius of action of data transfer is 10 m. Such obstacles as walls or other electronic devices can interfere with the signal transfer.
- . Turn on the speakers in Bluetooth mode.
- It is necessary to select the search mode of devices with Bluetooth on a signal source (telephone, notebook, smartphone, etc.). «SVEN PS-68» massage will be displayed on the screen which is to be connected to*.
- When connection is successful, there will be a short beep and the indication of the search mode on speaker system is over**.

Radio mode

To improve the reception quality of the radio signal, connect the power cable / audio microUSB – USB (included) to the input DC-LINE.

Turn on the speaker system – press button M ③ several times until speaker system
does not go to radio mode. Long press of a button ⑥ activates auto search mode.
After scanning completion, the first scanned radio station will start to operate
automatically. With buttons ⑥ and ⑥ select a desired radio station.

^{*}You might have to enter "0000" code to connect some models of devices via Bluetooth.

^{**} If the item has been already registered in the device list of a source, then the second search mode activation is not obligatory. Choose the item name "SVEN PS-68" and the "connect" command on the source.




Fig. 2. Connection diagram

Player mode

Attention! The file system of a micro SD carrier is FAT32. Maximum volume is 32 GB. It is not recommended to use the micro SD Ultra Speed.

 The system will enter the Player mode automatically when a carrier micro SD is connected to corresponding port. Use button (a) to switch between Play / Pause modes. You can control tracks by using button (b) (previous track) and button (c) (next track).

The use in the wired mode (AUX)

Connect the microUSB – 3.5 mm mini-jack (included) to the DC-LINE, and a 3.5 mm jack to the signal source.



TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Frequency range, Hz	speaker: 150 – 20,000; microphone: 50 – 16,000
Output power (RMS), W:	5
Membrane, mm	Ø 45
Radius of Bluetooth operation, m	up to 10
Battery capacity, mA / h	300
Power supply, V	USB/DC5
Weight, g	100
Dimensions, mm	73 × 81 × 40

Notes:

- Technical specifications given in this table are supplemental information and cannot give occasion to claims.
- Technical specifications and package contents are subject to change without notice due to the improvement of SVEN production.

Technical support is on www.sven.fi.





Model: PS-68

Импортер в России: ООО -РЕГАРД-, 109052. Фр. г. Моска, ул. Никегородская, д. 86, корп. Б. Уполномоченная организация в России: ООО -РТ-Ф-, 105082, г. Москва, ул. Фридрика Энгельса, д. 75, стр. Б. Условия гарантийного Обслуюшения смотрит в гарантийном талоне или на сайте www.sven.fl. Гарантийный доки: 12 мос. Срок службы: 2 года. Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингалур, 427447. Производитель опа, контролем - Свен Скацинавия Лимитед. 48310, Финляндия, Котка, Которахления Б. Спедван о В Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.



PS-68